

## INSTRUCTIONS





# BEFORE You begin

#### CAMPSITE SELECTION

- Select a smooth, level campsite clear of rocks, branches, and other hard or sharp objects
- Avoid areas with overhead power lines and tree limbs
- Park the vehicle in the chosen campsite
- Turn the engine off and engage the parking brake

## HOW TO STORE

- 1. Clean and dry the tent
- 2. Fold all of the components into the tent
- 3. Roll the tent, using the pole bag as a guide
- 4. Secure with the tent tie straps and insert
- into the carrying bag
- 5. Store in a cool, dry place

#### WARRANTY INFORMATION

Napier tents have a one (1) year warranty period from the time of purchase against defects in improper workmanship. Normal wear and tear, seam leakage through needle holes, and improper use, abuse, or alteration are not covered under the warranty policy. Napier Outdoors will replace or repair defective parts. Replacement parts may be new or re-built at Napier's sole discretion. E-Warranty claim forms can be completed online at www.napieroutdoors.com/warranty. Proof of purchase (receipt) must be provided. If you do not provide proof of purchase, or if your warranty period has ended, replacement parts can be purchased. **To order replacement parts, contact Napier Outdoors at 800-567-2434 (9:00 am – 5:00 pm EST), visit www.napieroutdoors.com, or email customerservice@napieroutdoors.com** 

#### CAUTION

- Do not use candles, matches, or open flames of any kind in or near the tent
- Do not cook inside the tent
- Build campfires downwind and several meters away from the tent. Be sure to fully extinguish fires before leaving a campsite or before retiring for the night
- Exercise extreme caution when using fuel-powered lanterns or heaters inside or around the tent. Use battery-operated lanterns whenever possible
- Do not refuel lamps, heaters, or stoves inside the tent
- Extinguish or turn off all lanterns before going to sleep
- Do not smoke inside the tent
- Do not store flammable liquids inside the tent
- NEVER run the vehicle engine when the tent is attached
- Do not install the tent when the temperature is below  $0^{\circ}C/32^{\circ}F$  or when your vehicle is wet, it may cause damage
- Allow adequate ventilation inside the tent at all times
- Do not attempt to drive the vehicle with the tent attached


### WARNING

- Keep all flame and heat sources away from the tent fabric. The tent is made with flame-resistant fabric which meets CPAI-84 specifications. This does not make it fireproof. The fabric will burn if left in contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.
- To prevent carbon monoxide from entering the vehicle and tent area, do not run the engine, do not cook inside the tent, and do not use a gas heater in the tent. Carbon monoxide is dangerous to your health.
- Engine must be off and exhaust must be fully cooled before tent installation and use.

### PACKAGE CONTENTS

#### If you are missing parts, please contact Napier Outdoors at 800-567-2434 | Monday - Friday or email customerservice@napieroutdoors.com


Remove contents from the bag and ensure you have all components listed below.



#### TENT SET UP

NOTE: Do not attach pole clips until all poles are in place in their pockets (step 7). Failure to do so will create too much tension and may cause pole to break.


For an easier assembly, set the tent up on the ground, completing steps 1-3 last.






2 Locate the tent side straps (3 per side) and loosely attach each to the truck's body.

3 Locate the tent tailgate straps (3). Slide the 3 back straps between the truck box and the tailgate (you may need to lift the tailgate). Locate the front straps at the end of the tailgate and connect to the corresponding back strap under the tailgate.



### ATTACHING THE RAINFLY

Locate the back of the rainfly that goes towards the cab of the truck (there will be a zippered access panel at this end) and drape over the tent.



(17 A

(17 B

#### SETTING UP THE AWNING

NOTE: Roll up the awning and secure with the toggles when not in use.

- Unfold each section of the NAVY BLUE fibreglass awning poles. Insert the poles into the ceiling of the awning, forming an X. Place the poles into the pockets at the corners of the awning.
- A. Unfold the top steel awning pole.
  B. Ensure the clasp is OPEN before connecting the poles.
  - C. Insert the top steel pole into the bottom pole (bottom pole has the plastic clasp).D. Adjust the height of the pole and close the clasp.
- Place the pin located at the bottom of the awning pole into the grommet hole at the tailgate of the tent. Place the top end of the pole into the grommet hole at the top corner of the awning.
- (b) Locate the straps on the corners of the awning and secure to the clip at the tailgate of the tent (beside the pole grommet hole).

#### **OPTIONAL:**

- **(6)** Secure the awning to the ground using 1 2 guy lines. Place the ring end of the guy line over the pole pin located at the top of the awning. Place the awning cap over the pin.
- Stake the bottom loop on the plastic slider of guy line (figure A) with a peg. Adjust the lenth of the rope by pushing the plastic slider upwards until the line is tight (figure B).